

CASE BLEND

CASING CLEANER

POWDER

CARBON

TARNISH



PRODUCT DESCRIPTION

CASE BLEND is a state-of-the-art, high-performance concentrate, formulated to make use of specific chemicals that acts with precision to remove carbon build-up, tarnish, and powder residue from casings.

CASE BLEND is Ammonia and Acetone free, biodegradable, and will not brittle or damage cases. CASE BLEND is safe to use in ultrasonic and rotary tumbling cleaners and cleans casing inside-out with ultimate efficiency.

500 ml | VLD - CAB500

RECOMMENDED DIRECTIONS

- 40:1 For normal to moderate cleaning required. (25ml/L H₂O)
- 20:1 For heavy to extreme cleaning required. (50mL/L H₂O)
- Using distilled water will increase the chemical's cleaning ability.
- The solution can be heated to between 50-60C in an ultrasonic cleaner.
- Casings and equipment can be treated for 15-20 minutes. Do not leave cases to soak in the solution for prolonged periods as this might discolor or tarnish cases. Rinse cases properly using tap water. Repeat the soaking process if the cases are not clean.
- After drying cases, tumbling can be done to ensure a shiny case finish.
- Ensure that cases are completely dry before use.

SPECIAL ABILITY

No need for making use of special recipes. This solvent makes use of an extreme dilution ratio to give you an added stretch without having your casings go pink.

CASE BLEND was engineered with specific natural products that are not harmful and will not damage Brass or Nickel.

Fast, reliable, and a one-stop solution for cleaning.

Superior cleaning ability with precision chemical technology for the precision enthusiast.



IMPORTANT NOTES

- Ensure that you clean your ultrasonic cleaners thoroughly after cleaning Brass. Copper and Zinc leached from the casings will settle on other equipment if present in the cleaner.
- It is advised to make a fresh batch of cleaning solution for every run to ensure product strength and that your casings are shiny every time.
- Do not leave equipment exposed for infinite amount of time without supervision as casings may tarnish.

RECOMMENDED

REMOVAL OF POWDER RESIDUE,
CARBON AND TARNISH FROM
BRASS AND NICKLE CASINGS

COMPATIBILITY

ROTARY TUMBLER
ULTRASONIC CLEANERS

LEGAL DISCLAIMER

Neither VELDT MARKSMAN nor the seller is responsible for how the user applies, handles or manipulates this product.

Neither VELDT MARKSMAN nor the seller is liable for warranties lost or implied nor any direct or indirect damage and injuries sustained, that might occur as a result of product misuse or acts conducted by the user. The user must read and keep to the directions supplied.

Please read the technical data sheet on our website: www.veldtsa.com

Not for human or animal consumption.

Always test the product on barrels and coatings before application.

Keep out of reach of children.

Store in a cool, dry place away from direct sunlight.



MAKE USE OF
GLOVES



USE EYE
PROTECTION



HARMFUL IF
SWALLOWED



BIODEGRADABLE
INGREDIENTS